

## **Product Description**

FX Penetrating Sealer is a water-based liquid specifically formulated to assist in addressing chalking and efflorescence problems.

Features Benefits

Water-based Ease of application
Easily sprayed Easy spreading
Easily brushed or rolled Easy clean-up

#### Uses

In most cases, assists in preventing chalking and reduces efflorescence on surfaces such as cement render, concrete slabs, bricks and fibre cement sheets.

Note: Recurring damp or salt problems need to be more fully addressed.

#### **Surface Preparation**

All surfaces must be thoroughly cleaned and free of dirt, dust, grease, loose or flaking paint, and loose surface plaster. Mould on masonry or concrete surfaces must be treated. Flatten gloss surfaces by thoroughly sanding and wipe clean with a damp cloth. Then apply FX Penetrating Sealer.

# **Application**

Stir contents thoroughly before and during use with a broad, flat stirrer using an upward action.

**Brush/Roller**: Product may be applied with a 100 mm brush or 20 mm roller.

Airless/Conventional Spray: Suitable for application using all standard spray equipment.

Approximate Spreading Rate: 12-14 square metres per litre, depending on application technique

and surface roughness.

Approximate Film Thickness per coat: Wet: 40 Microns; Dry: 10 Microns

**Requires**: 1–2 coats. **Thinner**: Not required.

Tinting: N/A.

**Method**: Brush, roller or conventional spray equipment. **Drying Times** (at 25 °C): **Touch**: 2 Hours; **Recoat**: 6 Hours.

Note: Do not apply paint if the air temperature or substrate temperature is below 10 °C or above 35 °C.

The temperature should bot fall below 10 °C during the drying process. Clean-up: Water. Safety: Dust Mask. Gloss Level: Not applicable.

# Safety and Environmental Care

### Safety

**Personal Protection:** Wear eye protection and dust mask when spraying, as splashes may cause eye irritation and inhalation of spray mist may cause respiratory irritation.

**Asbestos cement sheeting:** Do not disturb, sand or scrub, and avoid any peripheral dust. If you do not have professional expertise in handling/removal of asbestos sheeting, use a licensed asbestos removalist.

Refer to product labels, current FX Australia Safety Data Sheets or call FX Australia for detailed information.

### Clean-up

Slippery when spilled • Restrict access to area until clean-up is completed • When cleaning up spills, use personal protection equipment • Stop leak if safe to do so and contain spill with absorbent material such as sand, vermiculite or other inert material • Prevent spill from entering waterways • Collect and dispose of spilled material according to local regulations • Wash away remnants with liberal amounts of cold water.

### Storage

Store in a cool, dry, well-ventilated place out of direct sunlight • Store away from strong acids and moisture • Keep containers closed at all times and check regularly for spills.

## Disposal

Refer to State/Territory Land Waste Management Authority: most authorities permit disposal at approved land waste sites.

Date of Issue: March 2014